

Ricoh "35"

Camera Manual

For reference use on many Chinon, Ricoh and metering cameras

This camera manual library is for reference
and historical purposes, all rights reserved.

This page is copyright by mike@butkus.org, M. Butkus, N.J.

This page may not be sold or distributed without the
expressed permission of the producer
I have no connection with any camera company.

If you find this manual useful, how about a donation of \$3 to:

**M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701
and send your E-mail address too so I can thank you.**

**Most other places would charge you \$7.50 for a electronic copy
or \$18.00 for a hard to read Xerox copy.**

**This will allow me to continue to buy
new manuals and maintain these pages.**

It'll make you feel better, won't it?


If you use Pay Pal, you can click here to make a donation



www.PayPal.me/butkus


Venmo @mike-butkus-camera

[To main camera manual site](#)



Location of Parts:


<ol style="list-style-type: none"> 1. Film counter dial 2. Film loading winding knob 3. Film release button 4. Shutter release 5. Range finder lens 6. Accessory shoe 7. Viewfinder lens 8. Film rewind knob 	<ol style="list-style-type: none"> 9. Focusing lever 10. Flash terminal 11. Camera lens 12. Locking discs 13. Rapid winding trigger 14. Locking discs 15. 16. Range finder-viewfinder
--	---



The shutter speed dial (on lens) and aperture ring (on lens) are not pointed out.

LOADING YOUR FILM


1. Turn locking discs (12 & 14) on bottom of camera so that "O" position lines up with triangle. This unlocks camera back, which you gently slide down to expose rear of camera face.




2. Insert standard 35mm cartridge in left chamber, letting out 4 inches of film leader, which is inserted into slit in right take-up spool. (Fig. B) Be sure film's dull emulsion side faces the lens.

3. Turn film winding knob (2) so that film perforations engage sprocket gears.

4. Replace camera back by placing over front (Fig. A). Lock camera back by turning locking discs to original position "C".




5. Turn film winding knob (2) completely around twice, release automatic stop after first turn by depressing shutter release button (4). Line up "O" of film counter dial (1) with triangle mark. Rotate film winding knob one more complete turn. You're now ready to shoot!




After you have completed the roll, pull out film-rewinding knob (8), push film release button (3), and rewind the entire film into the original cartridge.

NOTE: Do not press shutter release button after you finish last exposure. Merely rewind and remove film cartridge from camera.

HOW TO TAKE PICTURES



Through the eyepiece of the range finder-viewfinder (16), you compose and focus your picture. In a contrasting colored section at the center of the image, a double image appears. When you turn the focusing lever (9), and the images coincide, your picture is in focus.



Set your lens opening and shutter speed, according to the film manufacturer's recommendations. When ready to shoot, depress release button (4).

TO USE FLASH GUN

Slip flash gun into accessory shoe (6) and attach cable to terminal (10) Shutter synchronizes to SF or SM flashbulbs at speeds to 1/50th second; or "O" delay electronic flash at all speeds.

RAPID SEQUENCE SHOOTING

When you pull rapid winding trigger (13) with left finger until it stops, film is wound and the shutter is wound, simultaneously. Compose picture in view-rangefinder and gently depress shutter release button (4). You can now shoot pictures as rapidly as you pull the lever and click the shutter!

YOUR DEPTH OF FOCUS SCALE

For normal snapshots, it is advisable to use the red line at the distance scale, and the red dot at the stop diaphragm. That gives you the so-called Fixed Focus (any objects between ∞ (infinity) and 10 feet are critically sharp). Also use the Depth of Focus Scale (Fig. 4), to determine the held of sharpness. For example, when distance is set at 10 feet, you will note that at f:16, all objects between 5 feet and infinity are sharp. At the same time, if diaphragm is set at f:8, objects between 7 feet and about 25 feet are share.



HOW TO HOLD YOUR CAMERA

Pull both elbows against your body to hold the camera steady (as illustrated).



For vertical camera position, release the shutter with your forefingers.

NOTE:

1: When using slow speeds, such as 1/10th sec., be certain to permit full shutter action before winding for next exposure.

2: Always be certain to wind fully before making exposure.

RIKEN Optical Industries, Ltd. · New York · Tokyo