## HOW TO USE TYPE II CLOSE-UP LENSES FOR TWIN-LENS REFLEX CAMERA





The close-up lenses consist of a viewing lens and a taking lens. Close-up photographs can be made by simply attaching both lenses to the camera.

## Mounting On the Camera

Attach the viewing lens and taking lens respectively to the bayonet mount of the camera, lenses by turning them until they come to a stop.

 When the viewing lens is mounted, the red dot must always point upward. (See photo)

## Taking Photographs

Follow the normal procedure in exposure setting and focusing.

- \* Use the smallest possible aperture setting because the depth of field (range in which all objects appear acceptably sharp) becomes shallow when the close-up lens is in use.
- \* When taking close-up photographs, even the slightest camera shake must be avoided. To prevent erratic movement of the camera at the critical moment of exposure the use of atripod and cable release is recommended.
- \* Careful focusing must be observed.

## Close-up Data

Two types of close-up lenses, No.1 and No.2, are available.





